

## TO USE AN ACTION CAMERA

1. Connect the phone mount to the top of the tripod head.
2. Use the screw to tighten the action camera to the mount by inserting the screw through the mount.



## USING THE LIGHT DIFFUSERS

The kit comes with 3 light diffusers - White, Blue and Orange - to create artistic lighting effects. The diffusers are swappable and fit over the light surface.

### Limits of Warranty:

Warranty coverage does not include the following:

- A faulty product that leads to harm or damage to other products
- Damage of product as a result of other product components
- Incorrect method of operation or use of product not for intended use
- Any form of alteration to original product
- Inability to install the product as a result of incompatibility with other components.

The Specifications are subject to change without notice.

### Disclaimer:

In no event shall GELID Solutions its directors or employees be liable for any indirect damages, Incidental or consequential damages arising from any defect or error in this manual or product.



(C) Copyright 2020 All rights reserved by GELID Solutions Limited  
All Brand names and Trademarks are the properties of their respective owners.

Please consult our website for further information:  
[www.gelidsolutions.com](http://www.gelidsolutions.com)

# ONAIR

## All-in-one Mbile streaming Kit

### Instruction Manual



## USING THE BLUETOOTH REMOTE

The Bluetooth remote is located under one of the legs of the tripod. From the inside of the leg, push the remote outward to release it.



## AT THE FIRST TIME, PAIR THE REMOTE WITH YOUR SMARTPHONE BEFORE USE

1. On your smartphone, go to settings and turn Bluetooth on.
2. Press and hold the remote button for 1 second.
3. The blue LED on the remote will blink to indicate it is in pairing mode.
4. On your smartphone you will see "remote control", select it to pair the devices.
5. Now turn on the camera, then press the shutter button on the remote to check if it is working correctly.


## USING THE CAMERA/ PHONE HOLDER

1. Open up the tripod and find the phone mount under the legs.
2. Grab the top and bottom of the mount and pull to release it from the tripod.
3. Attached it to the top of the tripod by screwing the button part of the mount into the top of the tripod.
4. Pull both the top and bottom panels of the mount to use enough space to insert your smartphone sideways into the mount.



## USING THE MICROPHONE WITH A PHONE

1. For iPhone 7 or newer, a Lightning to 3.5mm Audio Jack Adapter is required (purchased separately).
2. For USB-C smartphones, a USB-C to 3.5mm Audio Jack Adapter is required (purchased separately).
3. Connect the 3.5mm plug of the microphone cable directly into the 3.5mm audio jack of your smartphone or use the adapters above mentioned.
4. Make sure the microphone mode switch is in "Phone" position.
5. The microphone is now ready to use.



### Note:

If you hear interference on your recording, it means the lighting to 3.5mm adapter is not connected properly to your iPhone. You may need to remove the case of your phone (if any) to make better contact between the phone and the microphone.

## USING THE MICROPHONE WITH A CAMERA

1. Mount the microphone on top of the camera using the cold shoe found underneath.
2. Rotate the knob until the microphone fits securely on the camera.
3. Connect the 3.5mm plug of the microphone cable into the 3.5mm audio jack of the camera.
4. Push the microphone mode switch in "Camera" position. the red light indicator will turn on.
5. The microphone is now ready to use.

