



QUICK START GUIDE - AMD™ version

A Installation Parts




B Installation Instructions




1. Insert 4 x Screw F into the screw holes of Universal Backplate D and fasten 4 x Washer H as shown.
2. Unscrew and remove the standard AMD™ socket bracket and motherboard backplate.

C Installation Instructions





3. Insert the Universal Backplate Assembly from the motherboard backside and put 4 x Spacer G onto 4 x Screw F. (OPTIONAL): Place the AM4 Protective Bracket J on top of 4 x Spacer G.
4. Insert the 2 brackets of AMD™ Mounting Set C and tighten 4 x Thumbscrew E on top as shown.

D Installation Instructions



5. Apply Thermal Paste K on CPU surface (a small amount in centre is sufficient).
6. Peel off the protective film from the heatsink base.
7. Place the heatsink on top of CPU. Tighten the spring-screws with a screwdriver as shown.

E Installation Instructions



Limits of Warranty:
Warranty coverage does not include the following:
- A faulty product that leads to harm or damage to other products
- Damage of product as a result of other product components
- Incorrect method of operation or use of the product not for the intended use
- Any form of alteration to the original product
- Inability to install the product as a result of incompatibility with other components.

The Specifications are subject to change without notice.
Please consult our website for further information:
www.gelidsolutions.com

Disclaimer:
In no event shall GELID Solutions its directors or employees be liable for any indirect damages, incidental or consequential damages arising from any defect or error in this manual or product.

© Copyright 2021 All rights reserved by GELID Solutions Limited
All Brand names and Trademarks are the properties of their respective owners.