

Limits of Warranty:

Warranty coverage does not include the following:

- A faulty product that leads to harm or damage to other products
- Damage of product as a result of other product components
- Incorrect method of operation or use of product not for intended use
- Any form of alteration to original product
- Inability to install the product as a result of incompatibility with other components.

The Specifications are subject to change without notice.

Disclaimer:

In no event shall GELID Solutions its directors or employees be liable for any indirect damages, incidental or consequential damages arising from any defect or error in this manual or product.



©Copyright 2020 All rights reserved by GEUD Solutions Limited
All Brand names and Trademarks are the properties of their respective owners.

Please consult our website for further information:

www.gelidsolutions.com

LUX Tri-Color LED Ring Light User Manual



HOW TO CONNECT:

Plug the USB cable into an USB 5V port, and check the power button blue light is on.

CONTROL BUTTONS:



MOUNTING PHONE HOLDER:

Screw-in the phone holder to the base of the ring light



MOUNTING ON THE STAND:

Screw-in the ring light to the screw head of the included suction cup stand. It is also compatible with other stands carrying 1/4" screw mount.



USING THE SUCTION CUP STAND:

1. Pull up the latch before attaching.
2. Put the suction cup on a smooth, clear surface (glass, plastic, wood)
3. Press the latch down to secure the stand.
4. If it does not hold firmly, try to clean the contact surface and make sure there is no dust. If it still doesn't work, try another smoother surface.
5. To remove it, pull up the latch. If it does not detach, try to lift from the latch of the bottom plate.

